



HMA Construction Program

HMA Placement



Learning Objectives

- **State the Objectives of HMA Placement**
- **Identify Components and Function – Tractor and Screed Unit**
- **Describe Operational Principles of Screed**
- **Describe Grade and Slope Control Systems**
 - **Types**
 - **Functions**
 - **Capabilities**



Learning Objectives

- **Describe the Types of Paving and When to Use Them**
- **Describe Proper Paver Maintenance**
- **Describe Proper Operating Techniques**




Tractor Unit

- **Drive Systems**
- **Push Rollers and Truck Hitches**
- **Hopper**
- **Slat Conveyer**



Tractor Unit

- **Conveyer Flow Gates**
- **Augers**
- **Materials Feed System**
- **Tow Points**
- **Maintenance**





Tractor Unit



Courtesy of Caterpillar Paving Products



Track Drive



Courtesy of Caterpillar Paving Products



Truck Hitch






Push Rollers With Truck Hitch





Material Flow



Paver Hopper



Overflow Flashing



Slat Conveyors






Flow Gates





Adjustable Screw Augers



Courtesy of Caterpillar Paving Products




Adjustable Screw Augers




- Auger height affects mat texture
- Auger height 51 mm (2") above mat is right for most mixes
- Fine tune according to mix



Proper Head of Material




Courtesy of Caterpillar Paving Products




Kick Back Paddles

Kick Back Flights






Extendable Augers






Feed Control Sensors






Remote Feed Control



Tow Point





Screed Unit

- Screed plate
- Strike-off
- Crown control
- Extensions and end plates



Screed Unit


- **Thickness Control Screws**
- **Screed Arm**
- **Pre-Compaction System**
- **Heating Systems**
- **Maintenance**



Screed Unit




Screed Plate





Screed Plate






Strike-off Plate Adjustment




Screed Plate Crown Adjustment





Crown Adjustment



- A - Lead crown too high
Heavy mat'l flow in center **A**
- B - Lead crown too low
Heavy mat'l flow at edges **B**
- C - Uniform mat texture
and material flow from
correct crown adjustment **C**




Hydraulic Screed Extension



Courtesy of Caterpillar Paving Products



Mechanical Screed Extension






Screed End Plate





Cut-off Shoes





Thickness Control Screws






Thickness Adjustments



Courtesy of Caterpillar Paving Products





Screed Vibrators





VIBRATOR RPM & STROKE (AMPLITUDE)



FEWER IMPACTS PER
METER = LESS
COMPACTION




MORE IMPACTS PER
METER = INCREASED
COMPACTION



Screed Heaters




Diesel System



Electric System




Damaged Screed Plate






Screed Setup





Uneven Screed Wear






Operational Principles of the Screed

- Self-leveling Concepts
- Screed Response versus Distance
- Forces Acting on a Screed




Self Leveling - Rubber Tired Paver






Screed Reaction Time



- Screed reacts to change in angle of attack over 5 tow arm lengths
- 65% of change occurs in the first tow arm length
- 35% of change occurs in the last 4 tow arm lengths



Tow Point Effects






Main Forces Acting on Screed

1. Speed of Paver
2. Head of Material
3. Angle of Attack
4. Other Forces
 - Pre-compaction
 - Screed Weight



Screed Forces



Free Floating Screed


Screed
Weight

Forward
Motion

Material
Stability

Head of Material

Angle of
Attack





Head of Material

**Correct Depth of
Mat Maintained**




Constant Head of Material Volume

**Screed Rises Due to
Excess Material Forced
Under Nose of Screed**



Head of Material Volume Too High

**Screed Settles Due to
Inadequate Supporting
Material**



Head of Material Volume Too Low




Head of Material Effects

**Correct
Elevation**


**Auger
Overloaded**

**Auger
Underloaded**





Angle of Attack






Stopping the Paver?






Sticking the Mat?



Direction of Paving →



Screed Reaction Time




- Screed reacts to change in angle of attack over 5 tow arm lengths
- 65% of change occurs in the first tow arm length
- 35% of change occurs in the last 4 tow arm lengths



Manual vs. Automatic Adjustments



Grade and Slope Control





Types of Grade Reference

- Stringline
- Mobile reference
- Joint matching shoe
- Sonic sensor
- Laser



Stringline





Bridge Ski





Floating Beam





Contact-less Beam with Four Ultra Sonic Sensors






Joint Matching Shoe



Automatic Grade Sensor



Automatic Slope Control






Automatic Grade Control



Automatic Slope Controller

Automatic Slope Control





Paving Widths

- **Final Joint Location**
- **Multiple Lifts**



**Good Joint
Location?**



Night Paving





Night Paving

- **More common**
- **Requires more attention**
- **Issues:**
 - **Visibility**
 - **Cooler Temperatures**
 - **New Crews**
 - **Lighting**




Night Paving-Safety Issues



- Changes in Driving Habits
- Drunk drivers




Night Paving-Construction Issues



- Operator Awareness
- Equipment Maintenance
- Additional care during testing
- Impacts of limited lighting



Balancing Production






Warming Up






Screed in Position




Starting Blocks



A good rule of thumb is to raise the screed 20% to 25% more than the compacted thickness.



Setting Angle of Attack






Misaligned Screed Extension







Adjust Flow Gates



Gates too HIGH - augers overloaded



Gates too LOW - insufficient material supply



Correct adjustment - uniform material volume/flow



Start Up





Re-Check Settings

- Is thickness okay?
- Is cross slope okay?
- Is mat texture okay?



Check Settings





**Check
Thickness
And Head of
Material**



Check Paver Speed






**Check
Yield
Periodically**

Fold the Wings?





Don't Let This Happen!





Next Truck Not Ready?






Constant Head of Material





Minimal Luting





Minimal Luting



Paver Maintenance

- **Washing down**
- **Wear check**
- **Storage of electrical equipment**
- **Checklists**

Questions???

